

# 目次

機種一覧	3
住友製モータ製作範囲一覧表	5
形式記号	7

## ギヤモータ(三相モータ)

標準仕様	15
選定手順	17
負荷係数の選定	18

### ベベルパディボックス



選定表	
ホローシャフト形 モータ水平取付	23
ホローシャフト形 モータ立取付	43
寸法図	
ホローシャフト形	53
寸法図(オプション)	
ホローシャフト形 フランジ取付	57
ソリッドシャフト形 脚取付	58

### ヘリカルパディボックス



選定表	
ホローシャフト形 モータ水平取付	59
寸法図	
ホローシャフト形	77

## ギヤモータ (インバータ用モータ)

標準仕様	83
選定手順	85

### ベベルパディボックス



選定表	
ホローシャフト形 モータ水平取付 インバータ用モータ付	89
寸法図	
ホローシャフト形 インバータ用モータ付	95

### ヘリカルパディボックス



選定表	
ホローシャフト形 モータ水平取付 インバータ用モータ付	97
寸法図	
ホローシャフト形 モータ水平取付 インバータ用モータ付	103

## 技術資料

減速機部	107
モータ部	123

# CONTENTS

Available Combination	3
Basic Motor Specifications	6
Nomenclature & Mounting Positions	7

## Gearmotors (3-Phase Induction AC Motors)

Standard Specifications	15
Selection	17
Load Factor	19

### Bevel Buddybox



Selection Table	
Hollow Shaft Type Horizontal Motor Shaft Position	23
Hollow Shaft Type Vertical Motor Shaft Position	43
Dimension Table	
Hollow Shaft Type	53
Dimension Table (Option)	
Hollow shaft Flange type	57
Solid shaft type Foot Mount	58

### Helicall Buddybox



Selection Table	
Hollow Shaft Type Horizontal Motor Shaft Position	59
Dimension Table Standard Motors	
Hollow Shaft Type	77

## Gearmotors (AC Motors for Inverter)

Standard Specifications	83
Selection	85

### Bevel Buddybox



Selection Table	
Hollow Shaft Type Horizontal Motor Shaft Position Motors for inverter	89
Dimension Table	
Hollow Shaft Type Motors for inverter	95

### Helicall Buddybox



Selection Table	
Hollow Shaft Type Horizontal Motor Shaft Position Motors for inverter	97
Dimension Table Motors for inverter	
Hollow Shaft Type Motors for inverter	103

## Technical Data

Reducer	107
Motor	123